2008 Sterling with Mercedes-Benz engine

It has the TCM with the 80 pin connector. The ground speed pick up is on pin 25, but the wire # is 497K, 1803, instead of #125. It is the correct wire. The TCM is located on the plate that is bolted to the floor in lieu of the manual shifter hole. (easy to access. Just unbolt the floor plate and flip over.)